



Steps For Installing A Chain-Style Portable Door Lock



STEP 1

Test the fitting of the steel handle by inserting it between the door and the door frame.



STEP 2

If it fits well in the gap, open the door to install the portable door lock.



STEP 3

Insert the claw of the steel handle into the strike of the door.



STEP 4

While holding the lock, close the door with your other hand.



STEP 5

Insert the moving rod found on the plastic handle into the butterfly hole of the steel handle.



STEP 6

Leave the lock and try opening the door to test the lock.

Images source: Amazon