



Points To Remember When Installing Wall-Mounted Pull-Up Bars

Begin with reading the manufacturer's instructions carefully.



Install the pull-up bars at a height reachable with an extended arm.

Consider a height that ensures a headspace of at least 2 feet.



Ensure to drill into the studs for a secure grip, avoiding drywall damage.

Find the studs in your chosen wall with a stud finder.



Mark the drilling points for bracket placement to ensure accuracy.

Use a dowel rod and leveler to mark the points for extra precision.



Install the bars using manufacturer-provided hardware for a seamless process.