


Steps To Install A Flush Valve



Turn off the water supply and drain the water to empty the tank.

Remove the lid of the flush tank and mop its insides.



Detach the pipeline that supplies water to the toilet.

Remove the water tank by unscrewing its bolts.



Use a sturdy wrench to extract the broken flush valve.

Insert the new valve's spud into the water closet.



Insert the new valve in the tank and place it in the water closet.

Screw the bolts and reattach the water pipes to make them functional.

