

Steps Involved In Replacing A Toilet Fill Valve



Step 1

Cut off the water supply to the toilet and flush it to empty the tank.



Step 2

Place a plastic bin under the water supply hose.



Step 3

Detach the hose from the shank of the old fill valve under the tank.



Step 4

Unscrew the mounting nut that holds the old fill valve with a wrench.



Step 5

Open the flush tank lid and remove the float ball.



Step 6

Detach the refill tube from the overflow pipe and remove the old fill valve.



Step 7

Take the new fill valve and adjust its height to at least one inch above the overflow pipe.



Step 8

Insert the shank of the new fill valve in the tank.



Step 9

Fasten the mounting nut on the new fill valve under the tank.



Step 10

Adjust and attach the refill tube of the new fill valve to the overflow tube.



Step 11

Reconnect the water supply hose and switch on the water supply.