



Tips For Cleaning Skateboard Knee Pads

Air-dry the knee pads after use to prevent sweat-induced germ buildup.



Wash them in a washing machine if recommended by the manufacturer.

Avoid tumble-drying to prevent the padding from distorting.



Handwash the pads in a tub of cold water and detergent for a deep cleanse.

Add some vinegar to the soapy solution to combat any odor.



Let the pads soak in the soapy water for at least 30 minutes.

Rinse them well under running water till the water runs clear.



Always air-dry them thoroughly to prevent mold and mildew.